

move

WORK-EASY

by mobel linea


ADJUSTMENTS GUIDE






OPTIONAL HEADREST

Headrest
height
adjustment



Lumbar support
height adjustment







Synchro
mechanism



Synchro
mechanism with
automatic weight
adjustment






Seat height
adjustment




OPTION:


Seat depth
adjustment






5P synchro
mechanism







Weight
tension knob



Seat height adjustment






Synchro mechanism with
automatic weight adjustment

move


OPTION:

Seat depth
adjustment





5P synchro
mechanism with
automatic weight
adjustment



ARMS




1D




3D




Width adjustment




Arms height
adjustment




Arms height
adjustment



Arm-pads depth
adjustment



Arm-pads
rotation



Arms width
adjustment



MAINTENANCE

Clean the chair and its elements with a soft damp cloth and neutral detergent.

Check that the screws are tightly fastened periodically, if any.

Warning! Only qualified staff can replace or repair the components of the chair's height adjustment equipped with an energy storage device (piston)



USAGE INFORMATION

Seat for ONE person only! - Do NOT stand on the chair! - Do NOT use it as a step or ladder.

Option to choose casters with hard dual-wheels (suitable for carpet) or casters with soft dual-wheels for delicate floors (suitable for hard floors)

EN1335 Type B

mobel sit
by mobel linea

Ctra. de Guissona, Km. 1

Tel. (+34) 973 53 00 50

Fax (+34) 973 53 06 49

25200 CERVERA (Lleida) - SPAIN

E-mail: mobel@mobellinea.es